

3



4



5



2



1



Micro Roller Blind

1. Put masking tape mid way on the cassette, then mark the middle with a pencil. Find the centre of the window and centralise the cassette with the window at the fitting location and mark with a pencil.
2. Remove the screw cover caps at either end of the cassette, place the cassette to the marked position.
3. Screw through the two screw holes on the cassette, this will secure the blind in position. Then replace the screw cover caps.
4. Pull the blind down to your required position, and then mark the centre of the handle.
5. Let the blind retract and then screw the handle retaining bracket in the place you have marked.

Fitting instructions