

## Assembling the Universal Frame.



Carefully unwrap your new frame. Take care not to scratch if using a knife



Lay out the parts on a flat surface



Push the corners into the slots (you may need to tap lightly with a rubber hammer)



On the left and right uprights on the frame, you will find 4 sliding bracket carriers (2 on each side) these are movable so the brackets can be lined up with the bracket slots on the corresponding Perfect Fit blind when assembled.

This 'lug' locates into the slot on the blind



This picture shows the Universal frame lying next to the assembled Perfect Fit blind, and the bracket is being slid in line with the slot in the Perfect Fit frame. When all 4 brackets are lined up the Universal frame is ready to be screwed to the cabin side around the window opening

The holes for the screws which will attach the frame to the cabin side can also be seen in this picture. One in each corner.